SPECIALIST SUPPLIER TO THE GAME, FISHERIES AND GOLF INDUSTRIES.



<u>ASSEMBLING</u> TRANSPORT CRATE



Put the four corner-parts on the crate, making sure that the side of the corner-part with the vertical round hinge is towards the shorter side (to mount a door on it when required).



Put a piece of wood (or something to protect the plastic), on the corner-part and tap in using a mallet. The joining hooks will enter the proper cavities at the bottom.

WARNING: You can break the plastic hooks hammering directly on top of them.

If the corner-part is bent, tap on the longer side of it before and then on the shorter side driving the corner by hands. When inserting keep the corner-part slightly angled. After joining the four corners-parts, use the same method to attach the sides in the bottom of the crate.

Pay attention that the thicker ribs of the side are towards the inside of the crate. After doing this, lay the lid (top) upon the sides and the four corner-parts. (*This is the part with the sliding red door*)

Keep the sides and the four corner-parts in the right position by hand to allow hooks to enter the holes in the top.

Tap lightly around the lid, always putting wood between the mallet and the parts of the crate, starting from one point and going round the whole perimeter.

Check that all hooks are well fitted inside the holes of the bottom and of the top (lid).



Assemble the side door (red) of the crate on the round hinges, tapping slightly.

<u>Please Note</u>. If the temperature is low, to get a perfect assembly without breakages, we suggest warming the plastic parts in hot air or water, or at least, keeping them in a warm area before assembling.

UPTON DAIRY, UPLODERS, BRIDPORT, DORSET, DT6 4PH TELEPHONE: 01308 485422