EXPERIENCE SHARING OF BROOD BOX

- 1, THIS PRODUCT COMES WITH A 25-WATT UVB THERMAL LIGHT LAMP, WHICH IS A KIND OF HEATING LIGHT SOURCE THAT SIMULATES THE SUN. THE BENEFICIAL EFFECT OF ITS LIGHT ON SMALL ANIMALS CAN NOT BE COMPARED WITH THE COLD LIGHT SOURCE SUCH AS ENERGY-SAVING LAMP LED LAMP. LAMPS AND LANTERNS HAVE A CERTAIN LIFE, IF THE LONG-TERM SERVICE LIFE OF THE BULB IS BROKEN, YOU CAN GO TO THE STORE TO BUY THE ORIGINAL BULB, BUT ALSO TO THE HARDWARE STORE TO BUY 25-40W INCANDESCENT BULBS INSTEAD OF USING, MUST NOT USE ENERGY-SAVING LAMPS, LED LIGHTS AND OTHER COLD LIGHT.
- 2, THE USE OF INCUBATING BOX JUST CHU SHELL OF CHICKENS, CHICKS, NOT TRUSTING THERMOMETER, THE BEST WAY IS TO OBSERVE THE ACTIVITY OF THE CHICKENS: IF THE CHICKENS DO NOT LOVE TO MOVE, SHRINK INTO A GROUP, YOU NEED TO IMPROVE THE BRIGHTNESS OF THE LIGHT; IF THE CHICK OPENS ITS MOUTH TO BREATHE TO AVOID THE LIGHT, IT NEEDS TO REDUCE THE BRIGHTNESS OF THE LIGHT.
- 3, JUST OUT OF THE SHELL OF THE CHICKEN WILL NOT AUTOMATICALLY GO TO THE WATER FOUNTAIN TO DRINK WATER, CAN HOLD THE CHICKEN CHICKEN BEAK INTO THE WATER FOR TWO OR THREE SECONDS, AND THEN PUT THE CHICKEN NEXT TO THE WATER FOUNTAIN, SO THAT ALL THE CHICKENS CAN LEARN TO USE THE WATER FOUNTAIN.
- 4, JUST PICKLED CHICKEN, CHICKS WILL NOT USE AUTOMATIC FEEDER, CAN SCATTER FEED IN THE BROOD BOX, THE CHICKENS WILL AUTOMATICALLY PECK; DURING THE DAY, WHEN THE TEMPERATURE IS HIGH OR THE CHICKS ARE DEWARMED, THEY CAN BE TAKEN OUT OF THE BROOD BOX AND FED WITH A FEEDER.
- 5, THIS PRODUCT WITH SPECIAL WATER ABSORPTION NURSING PAD, CAN ACHIEVE DRY AND CLEAN FEEDING EFFECT, CLEANING CHICKEN FECES SUPER FAST AND CONVENIENT, WHEN USING, CAN BE AROUND THE NURSING PAD WITH A SMALL AMOUNT OF ADHESIVE TAPE ON THE WALL OF THE INCUBATOR, TO AVOID INDIVIDUAL NAUGHTY CHICKEN DRILLING INTO THE NURSING PAD BELOW.
- 6, SUMMER BROOD, IT IS BEST TO OPEN THE TOP COVER TO INCREASE AIR PERMEABILITY, SO AS NOT TO HIGH TEMPERATURE IN THE BOX; IN WINTER, IT IS GENERALLY NECESSARY TO COVER THE LID IN ORDER TO ACHIEVE BETTER INSULATION EFFECT.

THIS MANUAL TAKES THE SMALL BROODER BOX AS AN EXAMPLE. FOR OTHER MODELS AND SIZES, REFER TO THE INSTALLATION METHOD OF THE SMALL BROODER BOX. THE NUMBER OF ACCESSORIES VARIES WITH THE SIZE OF BROODER BOX.




THE HOT LIGHT



CERAMIC LAMP



LAMP COVER



THE THERMOMETER




EXPERIENCE SHARING OF BROOD BOX

- 1. THE PRODUCT COMES WITH A 25-WATT UVB THERMAL LIGHT LAMP, WHICH IS A KIND OF HEATING SOURCE THAT SIMULATES THE SUN. THE BENEFICIAL EFFECT OF ITS LIGHT ON SMALL ANIMALS IS THAT ENERGY-SAVING LAMPS, LED LAMPS AND OTHER LAMPS THAT CAN NOT BE COMPARED WITH COLD LIGHT SOURCES HAVE A CERTAIN LIFE. YOU CAN ALSO GO TO THE HARDWARE STORE TO BUY 25-40W INCANDESCENT BULBS INSTEAD OF USING, DO NOT USE ENERGY-SAVING LAMPS, LED LIGHTS AND OTHER COLD LIGHT.
- 2, THE USE OF INCUBATING BOX FEEDING JUST CHU SHELL CHICK CHICK, NOT TRUSTING THERMOMETER, THE BEST WAY IS TO OBSERVE THE ACTIVITY OF THE CHICK: IF THE CHICK DOES NOT LOVE TO SHRINK INTO A GROUP, YOU NEED TO IMPROVE THE BRIGHTNESS OF THE LIGHT; IF THE CHICK OPENS ITS MOUTH TO BREATHE TO AVOID THE LIGHT, IT NEEDS TO REDUCE THE BRIGHTNESS OF THE LIGHT.
- 3, JUST OUT OF THE SHELL OF THE CHICKEN WILL NOT AUTOMATICALLY GO TO THE WATER FOUNTAIN TO DRINK WATER, CAN HOLD THE CHICKEN CHICKEN BEAK INTO THE WATER FOR TWO OR THREE SECONDS, AND THEN PUT THE CHICKEN NEXT TO THE WATER FOUNTAIN, SO THAT ALL THE CHICKENS CAN LEARN TO USE THE WATER FOUNTAIN.
- 4, JUST PICKLED CHICKEN AND OTHER YOUNG BIRDS WILL NOT USE AUTOMATIC FEEDER, CAN SCATTER FEED IN THE BROOD BOX, THE CHICKENS WILL AUTOMATICALLY PECK; DURING THE DAY, WHEN THE TEMPERATURE IS HIGH OR THE CHICKS ARE DEWARMED, THEY CAN BE TAKEN OUT OF THE BROOD BOX AND FED WITH A FEEDER.
- 5, THIS PRODUCT WITH SPECIAL WATER ABSORPTION NURSING PAD, CAN ACHIEVE DRY AND CLEAN FEEDING EFFECT, CLEANING CHICKEN FECES SUPER FAST AND CONVENIENT, WHEN USING, CAN BE AROUND THE NURSING PAD WITH A SMALL AMOUNT OF ADHESIVE TAPE ON THE WALL OF THE INCUBATOR, TO AVOID INDIVIDUAL NAUGHTY CHICKEN DRILLING INTO THE NURSING PAD BELOW.
- 6, SUMMER BROOD, IT IS BEST TO OPEN THE TOP COVER TO INCREASE AIR PERMEABILITY, SO AS NOT TO HIGH TEM-PERATURE IN THE BOX; IN WINTER, IT IS GENERALLY NECESSARY TO COVER THE LID IN ORDER TO ACHIEVE BETTER IN-SULATION EFFECT.

BROOD BOX
ASSEMBLY INSTRUCTIONS








BROOD BOX INSTALLATION

STEP 1: RECOGNIZE PLATES AND PARTS AS SHOWN ABOVE STEP 2: PREPARATION

- 1. REFER TO FIGURE (1), INSTALL THE LAMP OPENING WITH WIRE ON THE ROOF WITH TWO SHORT SCREWS, AND FIX THE WIRE WITH WIRE CARD AND TWO SHORT SCREWS. INSTALL AND RESERVE.
- 2, THE ACRYLIC BOARD ON THE KRAFT PAPER PROTECTIVE FILM OFF STANDBY. REFER TO FIGURES (2) AND (3) AND INSTALL THE TWO SHAFTS ON THE ⑦ ACRYLIC CLAMSHELL WITH A SCREWDRIVER.







STEP 2: ASSEMBLE

- 1. ACCORDING TO THE OVERALL SHAPE OF THE BROOD BOX, THE WHOLE SHALL BE JOINTED TOGETHER THROUGH MORTISE AND TENON JOINTS. MATTERS NEEDING ATTENTION :(1) IN GENERAL, ASSEMBLE IN THE ORDER OF WHITE PLATE AND TRANSPARENT ACRYLIC PLATE; (2) THE WIRES ON THE TOP PLATE COME OUT THROUGH THE U-SHAPED HOLES ON THE ③ TAILGATE.
- 2. AFTER ASSEMBLY, SCREW THE LONG SCREWS ON THE RESERVED SCREW HOLES ON THE OUTER WALL AROUND THE INCUBATOR AND FIX THEM. POSITION OF LONG SCREWS: THERE ARE 5 SCREWS ON THE LEFT AND RIGHT SIDE PLATES, 9 SCREWS ON THE REAR BAFFLE PLATE AND 9 SCREWS ON THE BOTTOM PLATE, ALTOGETHER 28 SCREW POSITIONS.
- 3, INCUBATING BOX WITH PET URINALPAD, CAN ACHIEVE DRY AND CLEAN FEEDING EFFECT, CLEANING CHICKEN FECES SUPER FAST AND CONVENIENT, WHEN USING THE PET URINALPAD AROUND PART WITH A SMALL AMOUNT OF TAPE ON THE INCUBATOR WALL, TO AVOID INDIVIDUAL NAUGHTY CHICKS DRILLING INTO THE MAT BELOW. THE ASSEMBLY IS COMPLETE.